

# Laddomat 10 Spare parts list




## Termoventiler AB

Nolhagavägen 12  
SE - 523 93 MARBÄCK

Tel. +46 - (0)321 - 261 80  
Fax +46 - (0)321 - 261 89

info@termoventiler.se  
www.termoventiler.se

811038



3



1



2

Pos	Art. No	Benämning
1	111247	Laddomat 10 complete with RS 25-4/3, 3xR25-valves
2	111367	Laddomat 10 complete with RS 25-6/3, 3xR32-valves
3	111007	Laddomat 10 without pump and valves
4	371053	Thermostatic element 5840, 53°C
4	371057	Thermostatic element 8749, 57°C
4	371063	Thermostatic element 5839, 63°C
4	371072	Thermostatic element 8719, 72°C
5	211001	Piston LM 10 mounted
6	242006	Check valve with flap, complete
7		Gasket for ball valve
8	141003	Ball valve R25-40
9	321001	Lockring SW 42
10	410005	Cover
11	211007	LM 10-007 Mounted valvehouse
12	351002	O-Ring 44.12*2.62 epdm
13	351004	O-Ring 29.1*1.6 epdm
14	361003	Couplingnut R 1 1/2
15	141301	Ball valve R32-40