

# Laddomat 4030 Spare parts list



## Termoventiler AB


Nolhagavägen 12  
SE - 523 93 MARBÄCK

Tel. +46 - (0)321 - 261 80

Fax +46 - (0)321 - 261 89

info@termoventiler.se

www.termoventiler.se



Pos	Art no.	Description
1	113309	Contactkit for sensor LM 3000
2	113005	Sensor, Laddomat 3000, length 3m
3	113000	Laddomat 3000 Chargingregulator with sensor
4	114402	Coupling LM 4030
5	214001	LM 4000 Piston, mounted
6	214002	LM 4000 Valvehouse, complete
7	242003	Check valve, large
8	145003	Immersion for Laddomat 4030, L=480
9	363010	Pump Wilo RS 25/4-3-130
10	110053	Thermostatic element 5840, 53°C
10	110057	Thermostatic element 8749, 57°C
10	110063	Thermostatic element 5839, 63°C
11	141003	Ball valve R25-40
12	410005	Cover
13	410002	Featherseat
14	321001	Lockring
15	242005	Check valve, small
16	351002	O-Ring 44.12*2.62
17	351004	O-Ring 29.1*1.6
18	353000	Gasket
19	450002	Spring for piston LM 4000
20	361003	Couplingnut

814020-E